

Gasman

Replaceable battery version

Sensor Seal
M04682

i-Module Elastomer
E07621

LCD Bezel
M04854

LCD Display
E01873

Flow Cap
M04851

Front Moulding
M04855

LCD Elastomer
E07620

Disposable Battery
E01918

Clip Retaining Nut
M03705

Metal Clip
C03329
or
SS Alligator Clip
M02362

Rear Moulding Assembly
S011818/1

Case Screw
M03793

Elastomer Support
M04853

Charger Contact
E07649

Screw
M03792