

PTFE NEEDLE VALVES

These compact and reliable PTFE needle valves are designed for laboratory and industrial applications for regulating corrosive gases and liquids or for high purity service. They may also be used as shut off valves.

Pliant PTFE bodies of the valves are reinforced by structurally rigid metallic shells. Fluids contact only PTFE and PCT-FE materials. Shells are made of anodized aluminum or type 316 stainless steel and bushings are made of plated brass or 316 stainless steel. Where externally corrosive conditions exist stainless steel is recommended.

Valve spindles are made of rigid PCTFE to minimize the undesirable material "creeping" normally associated with PTFE. PTFE valves are designed for relatively high flow ranges while still performing well in low flow rates. Valves may be used in pressure or non-critical vacuum service.

The simplicity of design - there are only seven components (including a single PTFE o-ring) - assures reliability and minimizes sources of leakage. It takes seconds to disassemble the valve for cleaning and maintenance. The PTFE o-ring is radially compressed and due to this unique design feature the degree of compression may be adjusted without disassembly by tightening the hexagonal bushing.

ORDERING INFORMATION PTFE NEEDLE VALVES						
MODEL	MAXIMUM FLOW [ml/min]		CV	NON WETTED Materials		CONNECTIONS
NUMBER	AIR	WATER	00	SHELL	BUSHING	CONNECTIONS
VCL-TT-OA	2400	130	0.011	Aluminum	Brass	1/8" FNPT
VCH-TT-OA	55000	2800	0.250	Aluminum	Brass	1/8" FNPT
VCL-TT-OF	2400	130	0.011	Aluminum	Brass	1/4" Comp.
VCH-TT-OF	55000	2800	0.250	Aluminum	Brass	1/4" Comp.
VCL-TT-OG	2400	130	0.011	Aluminum	Brass	0.390 O.D. Glass Nipples
VCH-TT-OG	55000	2800	0.250	Aluminum	Brass	0.390 O.D. Glass Nipples
VCL-TT-2A	2400	130	0.011	Stainless	Stainless	1/8" FNPT
VCH-TT-2A	55000	2800	0.250	Stainless	Stainless	1/8" FNPT
VCL-TT-2F	2400	130	0.011	Stainless	Stainless	1/4" Comp.
VCH-TT-2F	55000	2800	0.250	Stainless	Stainless	1/4" Comp.
VCL-TT-2G	2400	130	0.011	Stainless	Stainless	0.390 O.D. Glass Nipples
VCH-TT-2G	55000	2800	0.250	Stainless	Stainless	0.390 O.D. Glass Nipples

design features

- ✓ Fluids contact PTFE and PCTFE only.
- ✓ Structurally Rigid Metal Shell.
- ✓ One PTFE o-ring.
- ✓ Simplicity only seven components.

Note: Based on 10psig (69 kPa) inlet pressure and atmospheric exhaust.



PTFE Needle valve with Stainless Shell and FNPT Fittings

SPECIFICATIONS		
MAXIMUM PRESSURE	75 psig (517 kPa)	
MAXIMUM TEMPERATURE	E 150 °F (65 °C)	
ORIFICE SIZE	0.125" diameter (3.175 mm)	
**MATERIALS OF CONSTRUCTION FLUID CONTACTING		
	Body and o-ring-PTFE.	
	Valve spindle-PCTFE.	
NON FLUID CONTACTING		
Shell - Aluminum (anodized) or 316 stainless steel. Bushing		
plated brass, or 316 stainle	ess steel. Adjusting Knob-phenolic.	

**The selection of materials of construction, is the responsibility of the customer. The company accepts no liability.

BARSTOCK VALVES

MVT[™] Metering valves are constructed of PTFE and PCTFE materials.

Non-fluid contacting external parts are made of anodized aluminum. Valves are offered in three

conveniently overlapping flow ranges. Safety handle prevents over tightening and facilitates fine metered regulation. MVT[™] valves are useful in regulating the flow of corrosive gases and liquids.

They may be used in pressure or non-critical vacuum service and serve as bubble tight shutoff valves.



PTFE Needle valve with Aluminum Shell and Glass Nipples



PTFE Metering Valve

ORDERING INFORMATION PTFE METERING VALVE					
MODEL NUMBER	MAXIMUM FLOW [ml/min]		Cv	CONNECTIONS	
NUMBER	Air	Water			
VM1-TT-OA	600	36	0.003	1/8" FNPT	
VM3-TT-OA	3000	180	0.015	1/8" FNPT	
VM6-TT-0A	30000	1800	0.150	1/8" FNPT	
VM1-TT-OF	600	36	0.003	1/4" Comp.	
VM3-TT-OF	3000	180	0.015	1/4" Comp.	
VM6-TT-OF	30000	1800	0.150	1/4" Comp.	
VM1-TT-OG	600	36	0.003	0.390 O.D. Glass Nipples	
VM3-TT-OG	3000	180	0.015	0.390 O.D. Glass Nipples	
VM6-TT-OG	30000	1800	0.150	0.390 O.D. Glass Nipples	

SPECIFICATIONS		
MAXIMUM PRESSURE	75 psig (517 kPa)	
MAXIMUM TEMPERATURE	150 °F (65 °C)	
ORIFICE SIZE	0.125" diameter (3.175 mm)	
NUMBER OF TURNS TO FULLY OPEN		
	Eight.	
STEM	Non-rising type.	
FLUID CONTACTING COMPONENTS		
	Body /o-ring-PTFE.	
	Valve spindle-PCTFE.	
NON-FLUID CONTACTING COMPONENTS		
	Shell + Handle - Aluminum (anodized).	

* Based on 10 psig (69 kPa) inlet pressure and atmospheric exhaust.



6mm PTFE NEEDLE

design features

- Fluids contact PTFE and PCTFE only.
- ✓ One PTFE o-ring.
- ✓ Simplicity, only six components.

PTFE needle valves are designed for laboratory and industrial applications for regulating corrosive gases and liquids or for high purity service. They may also be used as shut off valves.

Fluids contact only PTFE and PCTFE materials.

Valve spindles are made of rigid PCTFE to minimize the undesirable material "creeping" normally associated with PTFE.

PTFE valves are designed for relatively high flow ranges while still performing well in low flow rates.

Valves may be used in pressure or non-critical vacuum service.

The simplicity of design - there are only six components (including a single PTFE o-ring) - assures reliability and minimizes sources of leakage. It takes seconds to disassemble the valve for cleaning and maintenance.

The PTFE o-ring is radially compressed and due to this unique design feature the degree of compression may be adjusted without disassembly by tightening the bushing.



6mm PTFE Needle Valves

ORDERING INFORMATION FOR 6mm PTFE NEEDLE VALVES					
MODEL NUMBER	MAXII Flow		Cv	CONNECTIONS	
	Air	Water			
VT6-TT-0	300	9	0.765	3/8" FNPT	

Note: Based on 10psig (69 kPa) inlet pressure and atmospheric exhaust.

SPECIFICATIONS			
MAXIMUM PRESSURE	75 psig (517 kPa)		
MAXIMUM TEMPERATURE	150 °F (65 °C)		
ORIFICE SIZE	6.0 mm (0.250") diameter.		
**MATERIALS OF CONSTRUCTION FLUID CONTACTING			
	Body and o-ring-PTFE. Valve spindle-PCTFE.		
NON FLUID CONTACTING	Set screws 18-8 stainless steel.		